
EQUITONE

EQUITONE Exposed Fastener Using Vertical Girt Systems on Steel Stud Construction Details



Note: The detail numbers above correspond to the following index and pages of this detail book.

DISCLAIMER: These details are provided as a guideline for proper panel and associated component installation, and are based on industry accepted practices. Location of vapor barriers, insulation, and associated flashings and sealants in these details are based on ventilated rainscreen design practices for most U.S climatic Zones. (Primary vapor placed on the "warm" side of the insulation layer. Contact EQUITONE technical services for specific projects located in areas in extreme climate zones that may require modifications to these details. All structural and subframe supports are not by EQUITONE are shown to ensure TZ the contents of this publication are accurate, ETEX, SA/NV Group, and subsidiary companies do not accept responsibility for errors or for information, TZ is Found to be misleading. Suggestions for, or description of, the end use of application of products or methods of working are for information only and ETEX, SA/NV limited and its subsidiaries accept no liability in respect thereof.



DETAIL	CONTENT	PAGE
EQ-EF-VG-SS-FS	Relation Between Fixed and Sliding Points	4
EQ-EF-VG-SS-SUB	Relation Between Sub-Framing and Panel Expansion Points	5
EQ-EF-VG-SS-VP	Vertical Profile Details	6
EQ-EF-VG-SS-VJ	Vertical Joint Details	7
EQ-EF-VG-SS-OHJ	Open Horizontal Joint Details	8
EQ-EF-VG-SS-CHJ	Baffled Horizontal Joint Details	9
EQ-EF-VG-SS-BGL	Base Detail - Ground Level	10
EQ-EF-VG-SS-BOM	Base Detail - Junction with Other Facade Materials Details	11
EQ-EF-VG-SS-BCA	Base Detail - Covered Area	12
EQ-EF-VG-SS-BFR	Base Detail - Flat Roof	13
EQ-EF-VG-SS-BB	Base Detail - Balcony	14
EQ-EF-VG-SS-WHS1	Window Head and Sill Details - Option 1	15
EQ-EF-VG-SS-WHS2	Window Head and Sill Details - Option 2	16
EQ-EF-VG-SS-WJ	Jamb Detail Options	17
EQ-EF-VG-SS-C1	Coping Detail - Option 1	18
EQ-EF-VG-SS-C2	Coping Detail - Option 2	19
EQ-EF-VG-SS-OC	Outside Corner Detail	20
EQ-EF-VG-SS-IC	Inside Corner Detail	21
EQ-EF-VG-SS-SCO	Soffit / Ceiling Wall Junction - Outside Edge	22
EQ-EF-VG-SS-SCI	Soffit / Ceiling Wall Junction - Inside Edge	23
EQ-EF-VG-SS-CURVE	Curved Facade Details	24
EQ-EF-VG-SS-OM	Junction with Other Facade Materials Details	25
EQ-EF-VG-SS-FJ	Exposed Fastener - Concealed Fastener Junction	26

EQUITONE

RELEASE: 202412

REGION: NORTH AMERICA

WWW.EQUITONE.COM

INDEX

EQUITONE UNI-Fixing Color Matched — EQUITONE Fiber Cement Panel — EQUITONE UNI-Fixing Foam Tape — Galvanized Steel Z Channel* —

Gypsum Wall Board*

- Cold Formed Metal Framing*
- Wall Insulation*
- -Wall Sheathing*
- Air and/or Water Resistive Barrier*
- —Seal Fastener Penetrations'
- -Vertical Girt System*
- –Horizontal Joint Profile*
- -Cavity Insulation*

NOTE: THE DETAIL NUMBER ON EACH SHEET CORRESPONDS TO THE INDEX AND PAGE OF THE DETAIL BOOK

DISCLAIMERS:


THESE DETAILS ARE PROVIDED AS A GUIDELINE FOR PROPER PANEL AND ASSOCIATED COMPONENT INSTALLATION, AND ARE BASED ON INDUSTRY ACCEPTED PRACTICES. LOCATION OF VAPOR BARRIERS, INSULATION AND ASSOCIATED FLASHINGS AND SEALANTS IN THESE DETAILS ARE BASED ON VENTILATED RAINSCREEN DESIGN PRACTICES FOR MOST U.S. CLIMACTIC ZONES. (THE PRIMARY VAPOR PLACED ON THE "WARM" SIDE OF THE INSULATION LAYER. CONTACT EQUITONE TECHNICAL SERVICES FOR SPECIFIC PROJECTS LOCATED IN AREAS IN EXTREME CLIMATE ZONES WHICH MAY REQUIRE MODIFICATIONS TO THESE DETAILS. ALL STRUCTURAL AND SUBFRAME SUPPORTS ARE NOT BY EQUITONE AND ARE SHOWN FOR CLARIFICATION PURPOSES ONLY. TO ENSURE YOU ARE VEWING THE MOST RECENT AND ACCURATE PRODUCT APPLICATION GUIDE WWW.EQUITONE AND ARE SEN TAKEN TO ENSURE TZ THE CONTENTS OF THIS PUBLICATION ARE ACCURATE, ETEX, SANV GROUP AND SUBSIDIARY COMPANIES DO NOT ACCEPT RESPONSIBILITY FOR ERRORS OR FOR INFORMATION TZ IS FOUND TO BE MISLEADING. SUGGESTIONS FOR, OR DESCRIPTION ON, THE END USE OR APPLICATION OF PRODUCTS OR METHODS OF WORKING ARE FOR INFORMATION ONLY AND ETEX, SANV LIMITED AND ITS SUBSIDIARIES ACCEPT NO LIABILITY IN RESPECT THEREOF.

EQUITONE


RELEASE: 202412
REGION: NORTH AMERICA


WWW.EQUITONE.COM
























OPEN HORIZONTAL JOINT DETAILS












EQUITONE


13 / 27


RELEASE: 202412 REGION: NORTH AMERICA


WWW.EQUITONE.COM


FLAT ROOF











continuous open joint size specified in EQUITONE guidelines Where a perforated closure is not obstructing the inlet/outlet, the opening should be a minimum of 3/8 inch continuous
(*) symbol represents materials not supplied by EQUITONE.




DETAIL #: EQ-EF-VG-SS-C1 **RELEASE: 202412**

REGION: NORTH AMERICA

WWW.EQUITONE.COM


COPING DETAIL -OPTION 1





NOTES

- 1. The following transition from roof to parapet is valid for parapets under 24" in height. Otherwise see detail EQ-EF-VG-SS-BFR.
- Inlet/outlet, air cavity, and closure perforation sizing will vary, from those expressed herein, depending upon the distance between inlet/outlet or local legislation. Visit the Planning and Application Guide - Face Fixing to Metal for additional information.
- 3. When the inlet/outlet is wider than 3/4 inch continuous, a perforated closure is recommended to prevent debris build up. The perforation pattern should allow the same volume of air to pass through as the specified continuous open joint size specified in EQUITONE guidelines.
- 4. Where a perforated closure is not obstructing the inlet/outlet, the opening should be a minimum of 3/8 inch continuous.
- 5. Reduced section of the support profiles must be taken into account during static calculations.
- 6. (*) symbol represents materials not supplied by EQUITONE.












- All closures, trims, screens, etc. should be held off the back of the panel by at least 1/16 inch. Inlet/outlet, air cavity, and closure perforation sizing will vary, from those expressed herein, depending upon the distance between inlet/outlet or local legislation. Visit the Planning and Application Guide Face Fixing to Metal for additional information.
- When the inlet/outlet is wider than 3/4 inch continuous, a perforated closure is recommended to prevent debris build up. The perforation pattern should allow the same volume of air to pass through as the specified

- continuous open joint size specified in EQUITONE guidelines. Where a perforated closure is not obstructing the inlet/outlet, the opening should be a minimum of 3/8 inch continuous. (*) symbol represents materials not supplied by EQUITONE.










WWW.EQUITONE.COM



General Information

This document provides generic construction details for EQUITONE façade systems with exposed fasteners to assist with the design of the EQUITONE façade.

This document is not designed to serve as an installation guide and is intended to be used in conjunction with the relevant EQUITONE Planning and Application Guide and other technical and installation documents

The details included in this document only illustrate general principles for detailing EQUITONE at different typical interfaces and are not to be relied upon for weatherproofing and fire safety compliance with local regulations. The weatherproofing and fire performance of any project-specific detail or application shall be evaluated by the project engineer or consultant.

Any components related to wind barriers, fire safety, moisture management, and weatherproofing include but are not limited to membranes, flashing, water seals and sealants, airtightness tapes, horizontal and/or vertical fire barriers, etc. will need to be applied according to local regulations, project requirements, and relevant standards.

The support frame, fixings, flashings, and the like shall be of adequate corrosion resistance appropriate to the corrosivity category of the project location.

All dimensions in this document are in inches [in] unless otherwise stated.

The information in this guide is comprehensive but not exhaustive, and the reader will need to satisfy themselves that the contents of this guide are suitable for their intended application. It is the responsibility of the project consultants (designers, architects, and engineers) to ensure that the information and details provided in this document are appropriate for the project.

The information in this document is correct at the time of issuing. However, due to our committed program of continuous material and system development, we reserve the right to amend or alter the information contained in this document without prior notice. Please visit www.equitone.com to ensure you have the most current version.

This document is supplied in good faith and no liability can be accepted for any of or damage resulting from its use. Images and construction details contained in this document are not to a specific scale, are indicative and for illustration purposes only, and should not be used as final construction drawings.

This document is protected by international copyright laws. Reproduction and distribution in whole or in part without prior written permission is strictly prohibited. EQUITONE and logos are trademarks of Etex NV or an affiliate thereof. Any use without authorization is strictly prohibited and may violate trademark laws.



Please visit www.equitone.com for contact details further information and technical documents.



USA/Canada 1731 Fred Lawson Dr. Maryville TN, 37801 Tel: +1 865 268 0654 E-mail: info.usa@equitone.com

www.equitone.com

www.equitone.com/en-us/ www.equitone.com/en-ca/