P-A UNI-RIVET Manual v. AUG 2022



PLANNING & APPLICATION UNI-RIVET MANUAL



Disclaimer

The information in this manual is by no means exhaustive. This document has been developed to assist with the correct preparation and installation of EQUITONE panels. For full and detailed information about storage, handling, preparation, and design and installation requirements of EQUITONE, refer to EQUITONE Planning and Application Guide and other available EQUITONE relevant technical documents.

Refer to EQUITONE Material Safety Data Sheets (MSDS) or Safety Information Sheets (SIS) for more information about health and safety, including common hazards associated with working with EQUITONE, and measures to minimise risk.

The information in this document is correct at the time of issuing. However, due to our committed program of continuous material and system development we reserve the right to amend or alter the information contained in this document without prior notice. Please contact your local EQUITONE sales organisation or visit www.equitone.com to ensure you have the most current version.

This document is supplied in good faith and no liability can be accepted for any loss or damage resulting from its use. Images and construction details contained in this document are not to a specific scale, and are indicative and for illustration purposes only.

This document is protected by International copyright laws. Reproduction and distribution in whole or in part without prior written permission is strictly prohibited. EQUITONE and logos are trademarks of Etex NV or an affiliate thereof. Any use without authorisation is strictly prohibited and may violate trademark laws.

TABLE OF CONTENTS

TOOLS & ACCESSORIES

Page 3



TOOLS & ACCESSORIES

Centralising Tool	EQUITONE Care Toolkit
Centralising Tool Replacement drill bit 04.1mm	*LUKO Edge Sealer
Rivet Setting Tool	*LUKO Applicator
EQUITONE Fibre Cement Saw Blade	UNI-Rivet
EQUITONE Fibre Cement Drill Bit 011mm	UNI-Rivet Red/STOP Spacer
EQUITONE [linea] Milling Tool 011mm	Foam Tape
Aluminium Horizontal Joint Profile	Aluminium Perforated Closure

*Only for EQUITONE [natura] PRO & [natura]

STORAGE & HANDLING





EQUITONE [linea]			
Back Front		Back	
Front Front		Front	spacer
EQUITONE [tectiva] & [lunara	a]		
Front Front			Back Front
		5	
		3	
		2	
	t • 0	1	Max. height per pallet: 500 mm

PANEL CUTTING

TOOLS



Dust extraction system

EQUITONE fibre cement saw blade





Circular saw & Guide rail

> Styrofoam film blade





Stable Work Table With Sacrificial Board blade

PANEL CUTTING



PANEL EDGE TREATMENT

TOOLS







PANEL EDGE TREATMENT









PANEL DRILLING

TOOLS







PANEL DRILLING









PANEL DRILLING

EQUITONE [linea]





UNI-RIVET FIXING

TOOLS







UNI-RIVET FIXING









VENTILATION



* Refer to other relevant EQUITONE technical documents for the recommendations on the minimum sizes of ventilation inlets and outlets as well as minimum ground clearances.

** If perforated closure profile is used.

*** Cavity space X increases as the height of the facade & vertical distance IN & OUT increases.

INSTALLATION









*Optional Aluminium perforated closer











equitone.com

Follow us: f equitone facade equitone facade

